




The MimioView™ document camera works seamlessly with MimioStudio™ software to display documents, 3-D objects, and microscope slides for your entire class to view. You can use the MimioView camera to display still images or live video.



**View Button**

Press to open the MimioStudio View window and turn the camera and lights on.

Press again to close the MimioStudio View window and turn the camera and lights off.

**Status Lights**

**Off:** Not receiving power; USB cable is not connected or computer is turned off.

**Solid Green:** MimioView is connected and receiving power; MimioStudio software is running.

**Flashing Green:** MimioView is connected and receiving power; MimioStudio software is not running.